

Spares List

(F40-600S)

| Ref. | Part Number | Description | Material | Qty. |
|------|--------------------|---------------------|-----------------|------|
| 1 | F40H-21-01 | Sealing Plate | ABS | 2 |
| 2 | F40H-58-01/90*5.3 | O-Ring | EPDM | 4 |
| 3 | F40H-70-01/28*2.65 | O-Ring | EPDM | 4-8 |
| 4 | F40H-98-01 | Retaining Ring | 304SST | 2-4 |
| 5 | F40H-23-01 | Feed/Conc.Port | 2205SST/2507SST | 2-4 |
| 6 | F40H-22-01 | Bearing Plate | Aluminum Alloy | 2 |
| 7 | F40H-59-01/19*2.65 | O-Ring | EPDM | 4 |
| 8 | F40H-95-01 | Locking Kit Segment | 316LSST | 6 |
| 9 | F40H-09-01 | Permeate Port | ABS | 2 |
| 10 | F40H-10-01 | Plug | ABS | 1 |
| 11 | F40H-84-01 | Securing Screw | 304SST | 6 |
| 12 | F40H-61-01 | O-Ring | EPDM | 4 |
| 13 | F40H-11-01 | Strap | 304SST-Rubber | 2-3 |
| 14 | F40H-83-01 | Strap Screw | 304SST | 4-6 |
| 15 | F40H-03-01 | Saddle | Rubber | 2-3 |
| 16 | F40H-85-01 | Screw | 304SST | 2 |
| 17 | F40H-71-01/17*2.65 | O-Ring | EPDM | 4 |
| 18 | F40H-26-01 | Adapter | ABS | 2 |