

Spares List
(F80-450S)

Ref.	Part Number	Description	Material	Qty.
1	F80L-81-01	Locking Segment Screw	304SST	6
2	F80L-02-01	Spring Pad	304SST	6
3	F80L-03-01	Locking Kit Segment	304SST	6
4	F80L-31-01	Bearing Plate	Aluminum Alloy	2
5	F80L-10-02	Sealing Plate	ABS	2
6	F80L-51-01/187*7	O-Ring	EPDM	2
7	F80L-04-01	Feed/Conc.Port	316LSST	2-8
7.1	F80L-05-01	Feed/Conc.Port	316LSST	2-8
7.2	F80L-06-02	Feed/Conc.Port	316LSST	2-8
8	F80L-91-01	Retaining Ring	304SST	2-8
8.1	F80L-92-01	Retaining Ring	304SST	2-8
8.2	F80L-93-01	Retaining Ring	304SST	2-8
9	F80L-54-01/42.5*2.65	O-Ring	EPDM	2-8
9.1	F80L-55-01/54.5*2.65	O-Ring	EPDM	2-8
9.2	F80L-56-01/69*3.55	O-Ring	EPDM	2-8
10	F80L-08-02	Thrust Ring	ABS	1
11	F80L-52-01/36.5*3.55	O-Ring	EPDM	4
12	F80L-15-01	Adapter Pad	ABS	2-6
13	F80L-11-01	Adapter	ABS	2
14	F80L-53-01/23.6*2.65	O-Ring	EPDM	4
15	F80L-92-01	Retaining Ring	304SST	2
16	F80L-14-01	Plug	ABS	1
17	F80L-17-01	Strap	304SST-Rubber	2-3
18	F80L-82-01	Strap Screw	304SST	4-6
19	F80L-16-01	Saddle	Rubber	2-3
20	F80L-52-01/36.5*3.55	O-Ring	EPDM	1