

Spares List
(F80-300E)

Ref.	Part Number	Description	Material	Qty.
1	F80L-81-01	Locking Segment Screw	304SST	6
2	F80L-02-01	Spring Pad	304SST	6
3	F80L-03-01	Locking Kit Segment	304SST	6
4	F80L-21-01	Bearing Plate	Aluminum Alloy	2
5	F80L-22-01	Sealing Plate	ABS	2
6	F80L-51-01/187*7	O-ring	EPDM	2
7	F80L-23-01	Feed/Conc.Port	316LSST	2
8	F80L-92-01	Retaining-ring	304SST	2
9	F80L-57-01/47.5*3.55	O-ring	EPDM	4
10	F80L-08-01	Thrust Ring	ABS	1
11	F80L-52-01/36.5*3.55	O-ring	EPDM	4
12	F80L-15-01	Adapter Pad	ABS	2
13	F80L-11-01	Adapter	ABS	2
14	F80L-53-01/23.6*2.65	O-ring	EPDM	4
15	F80L-92-01	Retaining Ring	304SST	2
16	F80L-14-01	Plug	ABS	1
17	F80L-17-01	Strap	304SST-Rubber	2-3
18	F80L-82-01	Strap Screw	304SST	4-6
19	F80L-16-01	Saddle	Rubber	2-3
20	F80L-52-01/36.5*3.55	O-ring	EPDM	1